

CV1-2640

Controlled volatility electrically conductive RTV silicone

DESCRIPTION

- Two-part, black, electrically conductive RTV silicone
- 10:1 Mix Ratio (Part A:B)

Meets or exceeds the ASTM E 595 low outgas specifications outlined in NASA SP-R-0022A and European Space Agency PSS-014-702, with a TML of $\leq 1\%$ and CVCM of $\leq 0.1\%$

APPLICATION

- For applications requiring low outgassing and minimal volatile condensables under extreme operating conditions to avoid condensation in sensitive devices
- Use for RFI and EMI shielding in electrical and space applications
- Use to adhere covers onto housings or for any application where grooves and other configurations require a non-flowable to limited flow material

PROPERTIES

Typical Properties	Average Result	Standard	NT-TM
Uncured:			
Appearance, Part A	Black	ASTM D2090	002
Appearance, Part B	Clear	ASTM D2090	002
Extrusion Rate, tested 25 minutes after catalyzation (Performed using a SEMCO 440 nozzle with a 1/8" orifice and 90 +/- 5 psi air pressure)	300 g/min	ASTM C603	033
Extrusion Rate, tested 4 hours after catalyzation (Performed using a SEMCO 440 nozzle with a 1/8" orifice and 90 +/- 5 psi air pressure)	150 g/min	ASTM C603	033
Cured: 2 hours at 65°C (149°F)			
Appearance	Black, elastomer		
Specific Gravity	1.07	ASTM D792	003
Durometer, Type A	40	ASTM D2240	006
Tensile Strength	525 psi (3.6 MPa)	ASTM D412	007

Typical Properties	Average Result	Standard	NT-TM
Elongation	225%	ASTM D412	007
Volume Resistivity	25 ohm-cm	ASTM D257, D4496	040
Collected Volatile Condensable Material (CVCM)	0.03%	ASTM E595	072
Total Mass Loss (TML)	0.27%	ASTM E595	072

The test data shown for this material is the average value for typical properties. All of these properties may not be tested on a lot to lot basis and cannot be used to draft specifications. Please [contact](#) NuSil® for assistance and recommendations in establishing limits for product specifications.

INSTRUCTIONS FOR USE

Mixing

Thoroughly mix 10 parts Part A to 1 part Part B by weight just prior to use.

Vacuum Deaeration

Remove air entrapped during mixing by common vacuum deaeration procedure, observing all applicable safety precautions. Slowly apply full vacuum to a container rated for use and at least four times the volume of the material being deaerated. Hold vacuum until bulk deaeration is complete.

Note: Some bonding applications may require the use of a primer. NuSil SP-120 silicone primer is recommended.

Inhibition Concerns

Cures in contact with most materials. Exceptions include butyl and chlorinated rubbers, some RTV silicones and unreacted residues of some curing agents.

Note: Some bonding applications may require the use of a primer. NuSil CF1-135 silicone primer is recommended.

Adjustable Cure Schedule

Product cures at a wide range of temperatures and cure times to accommodate different production needs. [Contact](#) NuSil for details.

OPERATING TEMPERATURE

The operating temperature range of a silicone in any application is dependent on many variables, including but not limited to: temperature, time of exposure, type of atmosphere, exposure of the material's surface to the atmosphere, and mechanical stress. In addition, a material's physical properties will vary at both the high and low end of the operating temperature range. Silicone typically remains flexible at extremely low temperatures and has been known to perform at -50°C (-58°F) as well as resist breakdown at elevated

Packaging

100 Gram Kit (0.101 kg)
500 Gram Kit (0.505 kg)

Warranty

12 Months

temperatures up to 250°C (482°F). The user is responsible to verify performance of a material in a specific application.

ROHS AND REACH COMPLIANCE

Please [contact](#) NuSil's Regulatory Compliance department with any questions or for further assistance

SPECIFICATIONS

Do not use the typical properties shown in this technical profile as a basis for preparing specifications. Please [contact](#) NuSil for assistance and recommendations in establishing limits for product specifications.

WARRANTY INFORMATION

The warranty period provided by NuSil Technology LLC is 12 months from the date of shipment when stored below 40°C in original unopened containers. Unless NuSil provides a specific written warranty of fitness for a particular use, NuSil's sole warranty is that the product will meet NuSil's then current specification. NuSil specifically disclaims all other expressed or implied warranties, including, but not limited to, warranties of merchantability and fitness for use. The exclusive remedy and NuSil's sole liability for breach of warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. NuSil expressly disclaims any liability for incidental or consequential damages.

WARNINGS ABOUT PRODUCT SAFETY

NuSil believes, to the best of its knowledge, that the information and data contained herein are accurate and reliable. The user is responsible to determine the material's suitability and safety of use. NuSil cannot know each application's specific requirements and hereby notifies the user that it has not tested or determined this material's suitability or safety for use in any application. The user is responsible to adequately test and determine the safety and suitability for their application and NuSil makes no warranty concerning fitness for any use or purpose. NuSil has completed no testing to establish safety of use in any medical application.

NuSil has tested this material only to determine if the product meets the applicable specifications. (Please [contact](#) NuSil for assistance and recommendations when establishing specifications.) When considering the use of NuSil products in a particular application, review the latest Material Safety Data Sheet and [contact](#) NuSil with any questions about product safety information.

Do not use any chemical in a food, drug, cosmetic, or medical application or process until having determined the safety and legality of the use. The user is responsible to meet the requirements of the U.S. Food and Drug Administration (FDA) and any other regulatory agencies. Before handling any other materials mentioned in the text, the user is advised to obtain available product safety information and take the necessary steps to ensure safety of use.

PATENT / INTELLECTUAL PROPERTY WARNING

NuSil disclaims any expressed or implied warranty against the infringement of any domestic or international patent/intellectual property right. NuSil does not warrant the use or sale of the products described herein will not infringe the claims of any domestic or international patent/intellectual property right covering the product itself, its use in combination with other products, or its use in the operation of any process.